

MODEL 805YD PART NUMBERS

SIZES 2-1/2" to 10"

FIG. NO.	DESCRIPTION	QTY.	SIZE 2 1/2"	SIZE 3"	SIZE 4"	SIZE 6"	SIZE 8"	SIZE 10"
2	Seat Ring	2	101-145	101-144	101-136	101-137	101-138	101-139
2A	Bushing	2	780-280	780-280	780-281	780-281	780-282	780-282
2B	Seat Ring Screws (not shown)	8
3	Guide	2	190-001	190-002	190-003	190-004
4	Cover (See Cover Assembly)	2	880-094	880-095	880-081	880-082	880-083	880-084
4A	Bushing	2	780-312	780-312	780-313	780-313	780-313	780-313
5	Disc Holder (See Spring Assem.)	2	190-013	190-014	190-005	190-006	190-007	190-008
6	Disc Washer (See Spring Assem.)	2	190-016	190-017	190-009	190-010	190-011	190-012
7	Stem	2	780-332	780-333	780-334	780-335	780-336	780-337
7A	Screw	511-515-08	511-515-08	511-515-08	511-515-08
7B	Washer	2	780-338	780-338	780-338	780-338
9	Spring	...	780-341	780-342	780-343	780-344	780-345	780-346
11	Seat Disc	2	780-357	780-358	780-359	780-360	780-361	780-362
12	O-Ring	2	399-238-72	399-246-72	399-254-72	399-264-72	399-273-72	740-095
13	Capscrew	16	511-516-08	511-516-08	511-517-10	511-519-12	511-520-12	...
13	Capscrew	24	511-520-14
14	O-Ring	2	398-244-72	398-252-72	398-263-72	398-272-72	398-451-72	740-102
15	Locknut	2	521-547-00	521-547-00	521-550-00	521-550-00	521-551-00	521-551-00
16	Gasket	3	780-365	780-366	780-367	780-368	780-369	780-370
17	Bolt	12	511-019-18	511-019-20
17	Bolt	24	511-019-22	511-020-26	511-020-28	...
17	Bolt	36	511-021-30
17A	Nut	12	521-019-00	521-019-00
17A	Nut	24	511-019-00	521-020-00	521-020-00	...
17A	Nut	36	521-021-00
40	Bal Valve	4	781-047	781-047	781-047	781-048	781-048	781-048
41	Nipple (Not Shown)	4	571-181-44	571-181-44	571-181-44	571-181-55	571-181-55	571-181-55
Gate Valves								
42	Resilient Seated NRS-Inlet	...	781-005	781-006	781-007	781-008	781-009	781-010
42	Resilient Seated OS&Y-Inlet	...	780-891	780-893	780-895	780-897	780-899	780-901
42A	Resilient Seated NRS-Outlet	...	781-011	781-012	781-013	781-014	781-015	781-016
42A	Resilient Seated OS&Y-Outlet	...	780-890	780-892	780-894	780-896	780-898	780-900
50	Aircock	2	780-416	780-416	780-416	780-416	780-416	780-416
51	O-Ring	2	399-014-72	399-014-72	399-116-72	399-116-72	399-118-72	399-118-72
Assemblies/Kits								
...	Spring Assembly (3, 4A, 5, 6, 7, 7A, 7B, 9, 11, 15 and 51)	...	905-086	905-088	902-467	902-469	902-471	902-473
...	Rubber Parts (11 and 14)	...	905-059	905-060	905-061	905-062	905-063	905-064
...	Seat Kit (2, 2A, 2B and 12)	...	902-386YD	902-385YD	902-384YD	902-383YD	902-382YD	902-381YD
...	Lg. Mounting Kit (16, 17, 17A; Both Ends)	...	905-036	905-037	905-038	905-039	905-040	905-041
...	Cover Assembly (4, 4A, 14, 50)	...	902-497	902-498	902-499	902-500	902-501	902-502