

REPAIR KITS

How to order parts and repair kits.

1. Locate item number and kit number in this maintenance manual.
2. Verify the size of the valve the parts are to be used on.
3. Provide full model number located on I.D. plate.
4. Give kit number.
5. A serial number (located on the I.D. plate) will assist in ordering the proper kits.
6. Contact your local FEBCO Parts Distributor.

REPAIR KITS: MODEL 860 / 880 / 880V (2 1/2" - 10")

Kit Description	2 1/2"	3"	4"	6"	8"	10"
860/880 RP Inlet Spring Module						
Items						905-174(860)
2.1, 5.1, 7, 8, 9, 9.1, 10, 11, 12, 12.1	905-172	905-172	905-173	905-174	905-175	905-176 (880)
860/880 RP Outlet Spring Module						
Items						905-145(860)
2.1, 5.1, 7, 8, 9, 9.1, 10.1, 10.2, 11, 12, 12.1	905-142	905-142	905-143	905-144	905-145	905-146(880)
860 Disc Assembly						
Items						
2.1, 6, 16, 17	905-182	905-182	905-183	905-184	905-185	905-185
880 (V) Disc Assembly						
Items						
6, 16, 17 - (10" - item 6 only)	905-224	905-224	905-225	905-226	905-185	400-145
Seat Ring / Arm Assembly						
Items						905-160(860)
3, 3.1, 3.2, 3.3, 3.4, 4, 4.1, 4.2, 5	905-157	905-157	905-158	905-159	905-160	905-161(880)
860 Rubber Kit						
Items						
2.1, 3.1, 6, 15, 16, 17, 26, 27, 31.1, 32, 34.1, 35.1, 35.2, 45, 45.1	905-187	905-187	905-188	905-189	905-190*	905-190
880 (V) Rubber Kit						
Items						
2.1, 3.1, 6, 15, 16, 17, 26, 27, 31.1, 32, 34.1, 35, 35.1, 37, 45, 45.1	905-227	905-227	905-228	905-229	905-190*	905-191
Relief Valve Kit						
Items						
26, 27, 28, 29, 30, 31.1, 31.2, 32, 33, 34, 34.1, 37	905-192	905-192	905-192	905-192	905-192	905-192
Relief Valve Internal Assembly Kit						
Items						
27, 28, 28.1, 29, 30, 31, 31.1, 32, 33, 37, 38, 38.1, 39	905-320	905-320	905-320	905-320	905-320	905-320

Kit Description	2½"	3"	4"	6"	8"	10"
860 Cover Assembly Both Checks						
880 (V) Inlet Check Only						
Items						905-170(860)
2, 2.1, 15	905-167	905-167	905-168	905-169	905-170	905-171(880)
880 (V) Cover Assembly Outlet Check Only						
Items						
2.1, 2.5, 15	905-244	905-244	905-245	905-246	905-247	905-248
Bulkhead Fittings Assembly Cover						
Items						
43.1, 45.1, 46.1, 47.1	905-275	905-275	905-275	-	-	-
Bulkhead Fittings Assembly Body						
Items						
43, 45, 46, 47	905-276	905-276	905-276	-	-	-
Bulkhead Fittings Assembly Body and Cover						
Items						
43, 45, 46, 47	-	-	-	905-277	905-277	905-277
Bulkhead Plug Assembly 2nd Check Cover (N & V Units) Early Prod.						
Items						
44, 45.1, 46.1, 47.1	905-278	905-278	905-278	-	-	-
Bulkhead Plug Assembly 2nd Check Cover (N & V Units) Early Prod.						
Items						
44, 45, 46, 47	-	-	-	905-279	905-279	905-279
860 Relief Valve Assembly						
Items						
24, 24.1, 24.2, 25, 35.1, 35.2, 201	905-294	905-294	905-294	905-294	905-294	905-294
880 (V) Relief Valve Assembly						
Items						
24, 24.1, 25, 26, 35.1, 36, 50, 51, 201	905-295	905-295	905-295	905-295	905-295	905-295
860 Check Rubber Kit						
Items						
2.1, 3.1, 6, 15, 16, 17, 26, 35.1, 35.2, 45, 45.1	905-409	905-409	905-410	905-411	905-412	905-412
880(V) Check Rubber Kit						
Items						
2.1, 3.1, 6, 15, 16, 17, 26, 35, 35.1, 45, 45.1	905-413	905-413	905-414	905-415	905-412	905-416

Some of the above items are only available as part of a repair kit.
Note: Bulkhead fittings are not furnished on the Model 860.